



File Name: boston tvee 20 manual.pdf

Size: 1795 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 13 May 2019, 22:54 PM

Rating: 4.6/5 from 773 votes.

Status: AVAILABLE

Last checked: 16 Minutes ago!

In order to read or download boston tvee 20 manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with boston tvee 20 manual . To get started finding boston tvee 20 manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

boston tvee 20 manual

Ask your question here. Provide a clear and comprehensive description of the issue and your question. The more detail you provide for your issue and question, the easier it will be for other Boston Acoustics TVee 20 owners to properly answer your question. Ask a question I found the online manual for our Boston Acoustics TVee M20 sound bar, Is there a way that I can print this off so I can keep a copy of it If so, would you be so kind as to give me dumbed down instructions on how to do this. Thank you. Suzie T. Has anyone paired one with a different Soundbar. I have a Polk Bluetooth bar that is missing the Sub. Thanks This manual comes under the category Sound Bars and has been rated by 2 people with an average of a 8.5. This manual is available in the following languages English. Do you have a question about the Boston Acoustics TVee 20 or do you need help. Ask your question here Boston Acoustics TVee 20 specifications Brand The distance between the two devices that exchange data can in most cases be no more than ten metres. When the volume exceeds 120 decibels, direct damage can even occur. The chance of hearing damage depends on the listening frequency and duration. An HDMI cable is used to transport audio and video signals between devices. Dust in hard-to-reach places is best removed with compressed air. This makes it possible to create a 5.1 effect with only 1 speaker. ManualSearcher.com ensures that you will find the manual you are looking for in no time. Our database contains more than 1 million PDF manuals from more than 10,000 brands. Every day we add the latest manuals so that you will always find the product you are looking for. It's very simple just type the brand name and the type of product in the search bar and you can instantly view the manual of your choice online for free. ManualSearcher.com If you continue to use this site we will assume that you are happy with it. Read more Ok. A copy of the Declaration of Conformity DOC may be <http://www.soojuspilt.ee/files/copy-editing-manual.xml>

- **boston tvee 20 manual, boston tvee model 20 manual, boston soundbar tvee 20 manual, boston acoustics tvee 20 manual, boston acoustics soundbar tvee 20 manual, boston tvee model 20 instructions, boston acoustics tvee model 20 manual, boston soundbar tvee model 20 manual, boston acoustics soundbar tvee model 20 manual, boston acoustics tvee model 20 user manual, boston tvee 20 manual, boston tvee 20 manual, boston tvee 20 manual, boston tvee model 20 manual, boston acoustics tvee 20 manual.**

All it takes is the audio connection cable that is supplied. There are two likely sources for a signal—your television or a cable television connection box. The control box for a satellite system is for this purpose the same as a cable box. Then you can use the television remote control to adjust the volume as you normally do. Fine Tune TVee Now that things are up and running, it's time to adjust the bass unit to blend with the soundbar speakers so the system produces the balanced, natural Boston sound. What are they for If you have more than one TVee system in your house you can use different Wireless ID Switch settings so the systems won't interfere with each other. The warranty period for the electrical components of TVee is 1 year. EspaAaol. Sistema de Mejora del. Entretenimiento Televisivo. TVeeAZ Model 20. Francais. SystAme de perfectionnementA Boston P.O.P. Product. Make it your own. This equipment must be installed and operated in accordance with provided RF exposure compliance. See the table below. Power Button a Lets you manually activate TVee or put it in standby mode. Mute Button a Lets you temporarily mute TVee. Volume Up and Down Buttons a Let you manually adjust the volume of the TVee. Wireless ID Switch a Selects the channel for the wireless subwoofer signal. Set 11 in the same position. Trim Level Switch a Adjusts the input sensitivity of TVee. Inputs a Receives the input signal for the TVee. See the

Connect TV section for more information. Power Input a Connect the power supply 10 here. Power Supply a Provides power to the soundbar. Plug it into the wall and connect it to the power input 8. Green Steady. Normal power on mode. Green Blinks Once. Shows a remote control signal is being received. Orange Flashing. TV is ready to learn a remote control command. Orange Steady. The control button that is learning a control command is selected; TV waiting Flashing Green. TV has successfully learned a remote control command. Flashing Red. <http://pls.com.ng/fckeditor/editor/filemanager/connectors/php/userfiles/copy-editing-manual-pdf.xml>

TV has failed to learn a remote control command. Flashing Red and Orange. Indicates learned IR codes successfully erased. Set in the same position as 5. Volume a Adjusts the volume of the subwoofer to balance with the soundbar. Status Indicator a Lights red when the subwoofer is active and green when it is in standby mode. Power Fuse a Protects the subwoofer. Power Cord a Plug it into an AC outlet. Specifications. System Power Dimensions H x W x D. Soundbar. Subwoofer Weight. Subwoofer About TV. Congratulations on selecting TV for your home entertainment system. TV combines the famous Boston sound with From two compact components, TV delivers sound that will add an entirely new dimension Powerful amplifier and 3D sound processing circuitry ensure exciting performance. Wireless connection between the soundbar and subwoofer makes TV easy to set up the ideal combination of If necessary, TV can even learn the control signals from your remote control for maximum Placing TV. You are probably anxious to start using your TV so let's get started. First you should position It can be in front of the television. Or if your television is housed in furniture that has a But avoid places that are semi-enclosed. That can upset the natural sound balance of TV. There are keyholes in the The subwoofer is easy. It can go just about anywhere in the room. Since it gets its signal Just plug it into an AC outlet. Corner placement can help reinforce bass output. Next you need to get an input signal into the TV soundbar. All it takes is the audio connection cable that is supplied. There For simplicity we'll call it a cable box, but it could be either one. The main advantage of getting the signal from the cable box is that it is easier to set up. But if you have multiple signal The subwoofer receives a wireless audio signal from the soundbar you just need to plug it into your AC outlet. Television. Cable or Satellite Box

Botón de silencio a Le permite silenciar temporalmente el TV. Botones de aumento y disminución del sonido a Le permite ajustar manualmente el volumen del TV. Interruptor del nivel de ajuste a Ajusta la sensibilidad de entrada del TV. Entradas a Reciben la señal de entrada del TV. Vea la sección a Conectar el TV para más información. Normalmente se deja encendido en Alimentación a Proporciona la alimentación a la soundbar. Enchufe a la pared y conector a la entrada de Alimentación a Proporciona la alimentación a la soundbar. Enchufe a la pared y conector a la entrada de Verde fijo. Modo de funcionamiento normal. El verde parpadea una vez. Indica que se está recibiendo una señal del mando a distancia. Naranja destellante. El TV está preparado para memorizar un comando del mando a distancia. Naranja fijo. El botón de control que está memorizando un comando de control está seleccionado. TV está esperando un comando de IR para memorizar. Verde destellante. El TV ha memorizado con éxito un comando del mando a distancia. Rojo destellante. El TV no ha conseguido memorizar un comando del mando a distancia. Rojo y Naranja destellantes. Indica algunos de IR memorizados que se han borrado con éxito. Ajustelo en la misma posición Normalmente se deja encendido en Especificaciones. Potencia del Sistema Dimensiones H x W x D. Subwoofer Peso. Subwoofer Sobre el TV. Le felicitamos por la elección del TV para su sistema de entretenimiento doméstico. El TV combina el conocido sonido. Boston con una facilidad de utilización sin precedente. A partir de dos componentes compactos, el TV proporciona Amplificadores La conexión sin cable entre la Colocación del TV. Seguramente está deseando comenzar a utilizar su TV, de modo que empecemos. Primero debe colocar los componentes del TV. La soundbar debe colocarse de Puede

estar frente a la televisión. O si su pero evite ubicaciones que están semicerradas. Esto.

<https://ayurvedia.ch/3m-pipette-manual>

Hay bocallaves en la parte Es fácil situar la Subwoofer. Puede colocarse en cualquier lugar de la sala. Como recibe la simplemente encháfela en una Después necesita obtener una señal de entrada en la soundbar del TV. Todo lo que se necesita es el cable de conexión de Hay dos fuentes probables para una señal a su televisión o una caja de conexión de televisión por La ventaja principal de obtener la señal de la caja de cable es que es más fácil de configurar. Pero si tiene varias fuentes de la subwoofer recibe una señal de audio sin cable de la soundbar a lo que debe conectarla a su toma de CA. Televisión. Caja del cable o del satélite Voir le tableau cidessous. Bouton de mise en marche a Vous permet d'activer manuellement le TV ou de le mettre en mode d'attente. Bouton silence mute a Vous permet de couper momentanément le son du TV. Boutons de hausse et de baisse du volume a Vous permettent de régler manuellement le volume du TV. Interrupteur de sélection d'ID sans délai a Sélectionne le AT canal At du signal sans délai du Hautparleur de graves. Réglez l'Interrupteur du niveau de trim a Réglez la sensibilité d'entrée du TV. Voir la rubrique AT Connecter le TV At pour de plus amples informations. Entrée d'alimentation a Connectez l'alimentation électrique 9 ici. Normalement, il est allumé en permanence. Alimentation électrique a Alimente le soundbar en courant électrique. Branchez-le dans la prise murale et connectez-le A Vert fixe. Mode marche normal. Vert clignote une fois. Indique la réception d'un signal de télécommande. Orange clignotant. TV est prêt A apprendre une commande A distance. Orange fixe. Le bouton de contrôle qui apprend une commande de contrôle est sélectionné; TV Vert clignotant. TV a appris correctement une commande A distance. Rouge clignotant. TV n'a pas réussi A apprendre une commande A distance. Rouge et orange clignotant. Indique que les codes IR appris correctement et Zacs.

<http://gvshaw.com/images/case-695-sm-manual.pdf>

Réglez sur la même position que 5. Normalement, il reste allumé en permanence. Spécifications. Puissance du système Dimensions H x L x P. Hautparleur de graves Poids. Hautparleur de graves A propos de TV. Nous vous félicitons d'avoir choisi TV pour votre système de divertissement A domicile. TV combine le casier à son. Boston A une facilité d'utilisation sans précédent. A partir de deux composants compacts, TV délivre un son qui ajoutera des amplificateurs puissants et un circuit si nécessaire, TV peut même apprendre les signaux de contrôle A partir de votre télécommande pour une convivialité Positionnement du TV. Vous êtes probablement impatient de commencer A utiliser votre TV, alors, ne tardons plus. Vous devrez tout d'abord positionner Le soundbar doit être placé de manière A être centré avec l'écran Ou bien, si votre télévision est encastrée Ces situations La partie postérieure du boîtier du Le positionnement du hautparleur de graves ne pose pas de problème; il suffit de le placer Branchez-le Le positionnement dans une encoignure Ensuite, vous devrez obtenir un signal d'entrée dans le soundbar du TV. Tout ce dont vous avez besoin est le câble de raccordement L'avantage principal d'écouter de l'obtention du signal A partir du boîtier câble est que cela est plus facile A installer. Cependant, si vous A partir de la télévision, de telle sorte que vous puissiez profiter du son TV avec tous vos médias. Télévision. Boîtier câble ou satellite PDF Version 1.4. Linearized Yes. XMP Toolkit 3.1701. Producer Acrobat Distiller 7.0 Windows. Creator Tool PScript5.dll Version 5.2.2. Thumbnail Format JPEG. Thumbnail Width 256. Thumbnail Height 256. Thumbnail Image Binary data 6785 bytes, use b option to extract. Document ID uuid0BACC0C2A0EFDE11B87EF6196469B8D6. Instance ID uuid7a3c2e744cf4347b7b1a249bf1133ce. Derived From Instance ID uuid70fca30613d041e1b6a75709f8dfa892. Derived From Document ID xmp.did74117FB5200711689794EAEFB79FCA24.

<http://connect-log.com/images/case-60xt-user-manual.pdf>

Derived From Rendition Class proofpdf. Doc Change Count 1008. Creator mandyl. Page Count 24. Author mandyl. Giv en klar og omfattende beskrivelse af problemet og dit spørgsmål. Jo flere oplysninger du giver om dit problem og dit spørgsmål, jo lettere er det for andre Boston Acoustics TVEe 20 ejere at svare korrekt på dit spørgsmål. Stil et spørgsmål Om Boston Acoustics TVEe 20 Denne vejledning hører under kategorien Soundbar og er blevet bedomt af 2 personer med et gennemsnit på en 8.5. Denne manual er tilgængelig på følgende sprog Engelsk. Har du et spørgsmål om Boston Acoustics TVEe 20 eller har du brug for hjælp Stil dit spørgsmål her Boston Acoustics TVEe 20 specifikationer Mrke Hvis støjniveauet er over 120 decibel, kan der endda opstå direkte skader. Risikoen for høreskader afhænger af lyttefrekvensen og varigheden. Et HDMI-kabel bruges til at transportere lyd og videosignaler mellem enheder. Støv på vanskeligt tilgængelige steder fjernes bedst med trykluft. Dette gør det muligt at skabe en 5.1-effekt med kun 1 højttaler. PDFmanualer.dk sikrer, at du hurtigt kan finde den manual, du leder efter. Vores database indeholder mere end 1 million PDFmanualer fra mere end 10.000 mærker. Hver dag tilføjer vi de nyeste manualer, så du altid kan finde det produkt, du leder efter. Det er meget simpelt du skal bare indtaste mærke og produkttype i søgefeltet og du kan straks se den manual du ønsker, online og gratis. PDFmanualer.dk Hvis du fortsætter med at bruge dette site vil vi antage at du er indforstået med det. Ls mere Ok. You can if your TV support surround sound Any advise 1. Check the input cable or change it and see the result. 2. Test the subwoofer to a computer. Our Tvee 25 was working fine, like always, a couple. The Owners Manual says to change the fuse if the subwoofer is not working. I dont see any mention of where the fuse is or what type it is. The only statement containing Red status light will not change, stays RED I am also having the same problem.

It was working fine until we moved. Plugged it in at the new house and nothing but a red. To make sure thier not loose. Bought a used I have tried everything thing possible even the Boston support but to no. Install in accordance with the manufacturer's instructions. 8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus including amplifiers that produce heat. 9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. Servicing is required when the apparatus has been damaged in any way, such as powersupply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been This class B digital apparatus complies with Canadian ICES003. Cet appareil numerique de classe B est conforme a la norme NMB003 du Canada. The ventilation should not be impeded by covering the ventilation openings or placing on or around the apparatus items such as newspapers, tablecloths, curtains, etc. 15. No open flame sources, such as lighted candles, should be placed on the apparatus. 16. The apparatus shall not be exposed to dripping or splashing. 17. Either the power inlet connector on the rear of the apparatus or the power plug at the wall must remain accessible, to be able to disconnect power from the apparatus. 18. 19. To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. WARNING Please refer the information on exterior bottom enclosure for electrical and safety information before installing or operating the apparatus. 25. When not in use and during movement, please take care of the power cordset, e.g.

www.uppld.org/wp-content/plugins/formcraft/file-upload/server/content/files/1626f7f902911e---bose-302a-manual.pdf

tie up the power cordset with cable tie or something like that. It shall be free from sharp edges and the like that can cause abrasion of the power cordset. When put into use again, please make sure the power cordset being not damaged, If any damages found, please look for the service person to

replace the power cordset specified by the manufacturer or have the same characteristics as the original one. 26. Warning To reduce the risk of electric shock, do not remove cover or back as there are no userserviceable parts inside. Refer servicing to qualified personnel. No objects filled with liquids, such as vases, shall be placed on the apparatus. Note This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC American Users Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equip ment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. This symbol found on the apparatus indicates hazards arising from dangerous voltages. This symbol found on the apparatus indicates the user should read all safety statements found in the user manual. This symbol found on the apparatus indicates double insulation. Warning!

To reduce the risk of fire or electrical shock, do not expose this apparatus to rain or moisture. Canadian Users RLAN Radio Local Area Network Equipment This equipment may only be used indoors in FR. This equipment may only be used in one's own premises in IT. This equipment is for private use only in LU Operation is not allowed within a radius of 20 km from the centre of NyAlesund in NO. Place Y our Sy stem Decide on the location and position of the system before making any connections. Soundbar Location Place the soundbar on a table surface or shelf near the television, or wallmount the soundbar above or below the television. A mounting template can be found in the product carton. Using a level tool, position and tape the template to the wall in the desired location. For the best sound, place the subwoofer near a wall or corner within 20 feet 6 meters of the soundbar on the same side of the room as the soundbar. The wireless subwoof er range is 25 feet 8 meters. Be careful to avoid placing the subwoofer in a position where curtains or blankets block the sound. Connect your sy stem Next you need to get an input signal from your T V into the TVee soundbar. Select from two easy options. Option 1 preferred Optical digital cable. Note Or Option 2 RCA stereo audio cable. Use if your T V does not have an Optical Out. If you have a TV with RCA outputs, please use the RCA to mini cable adaptor as shown, if the TV has 3.5mm output, then you don't need the adaptor. Connect the subwoofer power cord to the subwoof er. Plug both into AC power outlets. 2. Turn ON the rear panel po wer switch 18 on the subwoofer. The wireless subwoofer connects to the soundbar automatically. Pairing the soundbar and subw oofer The subwoofer and soundbar are paired at the factory. However if the communication is interrupted please follow this simple procedur e. 1. Press the Pair Button 20 on the subwoofer until the S tatus Indicator 21 ashes red. 2.

Press the Pair Button on the back of the soundbar. The Sta tus Indicator 21 on the subwoofer will be solid green. Status Indicator 21 Red LED Subwoofer not paired to, or searching for TVee soundbar Green LED Subwoofer is paired to TVee soundbar. Y our system is ready. Note The lights only illuminate temporarily to show a mode or function change. Using the rear panel A uxiliary Input Use the rear panel AUX 1 or A UX 2 Inputs to connect a portable media device. How do I wa tch T V Select an input Use the front panel Input Button to choose an input. Each time the Input Button is pressed, the input changes in sequence from Optical Digital In to analog Aux 1 input to analog Aux 2 input back to Optical Digital In. The color of the Input Mode Light indicates which input is selected. Input Button Light 3 Green Optical Digital In is selected. Orange Analog Aux 1 input is selected. Red Analog Aux 2 Input is selected. To cancel audio muting, push the M u te B u tto n, V ol u me Do w n B u tto n, or V ol u me Up B u tto n. The TVee 26 will remember whatever mode was last chosen f or

each input. The warranty period for the electrical components of T Vee is 1 year. The producer paid to recycle this product. Dolby y el símbolo de la doble D son marcas registradas de Dolby Laboratories. 23. Cuando no está en uso y durante un desplazamiento, tenga cuidado con el cable de alimentación, por ejemplo, atape el cable eléctrico con una sujeción de cable o algo similar. No debe tener bordes filosos y cosas parecidas pues podría raspar el cable de alimentación. Al volver a ponerlo en uso, verifique que el cable de alimentación no esté dañado. Si se detectan daños, por favor pida al personal de mantenimiento que reemplace el cable de alimentación especificado por el fabricante o que tenga las mismas características que el original. 24.

Advertencia Para reducir el riesgo de choque eléctrico, no retire la tapa o parte trasera pues adentro no hay piezas de mantenimiento para el usuario. Deje que el servicio técnico lo realice personal calificado. Usuarios estadounidenses Nota Este equipo ha sido probado y se ha determinado que cumple con los límites para un dispositivo digital Clase B, de acuerdo con la parte 15 del Reglamento de la FCC. Estos límites están destinados a ofrecer protección razonable contra la interferencia perjudicial en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza según las instrucciones, puede ocasionar interferencia perjudicial para las radiocomunicaciones. Sin embargo, no hay garantía de que no se produzca interferencia en una instalación en particular. Si este equipo efectivamente ocasiona interferencia perjudicial a la recepción de radio o televisión, lo que se puede determinar apagando y encendiendo el equipo, se recomienda al usuario intentar corregir la interferencia implementando una o más de las siguientes medidas Reorientar o reubicar la antena receptora. Aumentar la separación entre el equipo y el receptor. Conectar el equipo a un circuito distinto al que está conectado el receptor. Usuarios canadienses Este aparato digital clase B cumple con la norma canadiense ICES003. Usuarios europeos RLAN Radio Local Area Network Equipment Equipo de red radioeléctrica de área local Este equipo solo puede usarse en interiores en FR. Este equipo solo puede usarse en sus propias instalaciones en IT. Este equipo es solo para uso privado en LU. No se permite utilizarlo dentro de un radio de 20km del centro de NyAlesund en NO. Este símbolo que aparece en el aparato indica que el usuario debe leer todos los avisos de seguridad del manual del usuario. Un enchufe polarizado tiene dos patas, una más ancha que la otra.

Un enchufe de puesta a tierra tiene dos patas y una tercera de puesta a tierra. La pata ancha o la tercera pata es para su seguridad. Si el enchufe provisto no encaja en el toma, consulte a un electricista para reemplazar el toma obsoleto. 10. Proteja el cable de alimentación para que no se lo pise ni apriete, especialmente en los enchufes, en los receptáculos, y en el punto donde salen del aparato. 11. Utilice únicamente aditamentos o accesorios especificados por el fabricante. 12. Desenchufe el aparato durante tormentas eléctricas o cuando no se lo utilice durante períodos largos. 13. Toda la asistencia técnica debe ser proporcionada por personal de servicio calificado. Se requiere asistencia técnica cuando el aparato se ha deteriorado de cualquier manera; por ejemplo se ha dañado el cable de alimentación o el enchufe, se ha derramado un líquido o caído un objeto dentro del aparato, se ha expuesto el aparato a la lluvia o la humedad, el aparato no funciona normalmente o se ha caído. 14. Mantenga una distancia mínima de 2 " 50mm en el frente, la parte posterior y los lados del aparato, para que el mismo tenga suficiente ventilación. No se debe obstaculizar la ventilación cubriendo las aberturas de ventilación ni colocando sobre o alrededor del aparato elementos como perifericos, manteles, cortinas, etc. 15. No se deben colocar fuentes de llama expuesta, por ejemplo, velas encendidas, sobre el aparato. 16. El aparato no se debe exponer a goteos ni salpicaduras. No se deben colocar objetos llenos de líquido, por ejemplo, floreros, sobre el aparato. 17. Tanto el conector de entrada de alimentación de la parte posterior del aparato como el enchufe de la pared deben permanecer accesibles, para poder desconectar la energía del aparato. 18. Para desconectar totalmente el aparato de la red de CA, desconecte el cable eléctrico del tomacorriente de CA. 19.

Use solamente el carrito, la base, el tri pòde, soporte o mesa que indica el fabricante o que se vende con el aparato. Normalmente se mantiene encendido. Enchufelo a la pared y conéctelo a la entrada de alimentaci3n. U bicaci3n del sistema Decida la ubicaci3n y posici3n que va a ocupar el sistema antes de hacer las conexiones. U bicaci3n de la barra de sonido Coloque la barra de sonido sobre una mesa o estante cerca del televisor, o instálela en la pared por encima o debajo del televisor. Normalmente es mejor no colgar la barra de sonido de la pared antes de hacer las conexiones. Conecte el cable de alimentaci3n del subwoofer al subwoofer. Enchufe ambos en los tomacorrientes de CA. 2. Encienda el interruptor de encendido del panel posterior 18 del subwoofer. El subwoofer inalámbrico se conecta automáticamente a la barra de sonido. Asociaci3n de la barra de sonido y subwoofer. El subwoofer y la barra de sonido son asociados en fabrica. Sin embargo, si se interrumpe la comunicaci3n, por favor siga este procedimiento simple. 1. Presione el Bot3n de Asociaci3n 20 del subwoofer hasta que el Indicador de Estado 21 destelle en rojo. 2. Presione el Bot3n de Asociaci3n que est3 en la parte posterior de la barra de sonido. El Indicador de Estado 21 del subwoofer I ndicador de E stado 21 LED rojo El subwoofer no est3 asociado o est3 buscando la barra de sonido del T Vee. LED verde El subwoofer est3 asociado a la barra de sonido del T Vee. Su sistema est3 listo. Nota Las luces solo se encienden temporalmente para mostrar un cambio de modo o funci3n. U so de la entr ada auxiliar del p anel p osterior Utilice las entradas AUX 1 o A UX 2 del panel posterior para conectar a un dispositivo de medios portatil. C o mo miro la TV Selecci3n de una entrada Use el Bot3n de Entrada del panel frontal para elegir una entrada.

Cada vez que se presiona el Bot3n de Entr ada, la entrada cambia de secuencia de Entrada Digital Optica a entrada Aux 1 anal3gica, nuevamente a entrada A ux 2 anal3gica, nuevamente Entrada Digital Optica. El color de la Luz de Modo de Entrada indica que entrada est3 seleccionada. L u z del Bot3n de E ntr ada 3 Ver de La Entrada digital optica est3 seleccionada. Naranja La entrada Aux 1 anal3gica est3 seleccionada. Roja La entrada Aux 2 anal3gica est3 seleccionada. Para silenciar el audio, use el Bot3n de silencio. Para cancelar el silencio de audio, presione el Bot3n de silencio, el Bot3n para bajar el volumen, o el Bot3n para subir el volumen. ABC Activa la barra de sonido en Modo Reconocimiento Elija la funci3n de la barra de sonido que desea reconocer. Dolby et le symbole doubleD sont des marques deposes de Dolby Laboratories. 23. Lorsqu il n est pas utilisé et pendant le mouvement, veuillez prendre soin du c a ble d alimentati3n, par exemple, attacher le c a ble d alimentati3n avec un serre c a ble ou equivalent. Il doit étre exempt de bords tranchants et de tout ce qui peut causer l abrasion du c a ble d alimentati3n. Lors de la remise en service, veuillez vous assurer que le c a ble d alimentati3n n est pas endommagé. Si des dégradations sont trouvées, veuillez demander a la personne en charge des reparations de remplacer le c a ble d alimentati3n spécifiée par le fabricant ou ayant les m émes caractéristiques que l original. 24. Avertissement Pour réduire le risque de choc électrique, ne pas retirer le couvercle ou le dos car il n existe pas de pi éces réparables par l utilisateur a l intérieur. Confier les reparations a un personnel qualifié. Utilisateurs américains Remarque Cet équipement a été testé et déclaré conforme aux limites relatives a un appareil numérique de classe B conformément a la partie 15 des R èglements de la FCC.

<https://skazkina.com/ru/3m-pipette-manual>